


Fig. 1



FIG. 3



300

102

114'

104

114

Fig. 3






Fig. 5



700

716

User mode  
Executable

Hardware Event  
Server Executable

714

4 user mode

## Kernel Streaming Proxy

- 712

## Kernel mode

Device Driver

710

USB host Controller/  
Driver

708

host

704  
USB BUS

↓ Camera

706

702  
CLICK

Fig. 7

[illegible]